

FLOOR JOIST SPAN LIMITATIONS 10psf Dead Load and 100psf Live Load (TL Deflection=L/240)

Member	Yield strength F <sub>y</sub> (ksi)	Live Load Deflection L/360						Live Load Deflection L/480						
		Single span spacing (in) o.c.			Two equal span spacing (in) o.c.			Single span spacing (in) o.c.			Two equal span spacing (in) o.c.			
		12	16	24	12	16	24	12	16	24	12	16	24	
600S137-33	33	7'1"e	6'1"e	5'0"e	6'10"a	6'10"a	4'1"a	7'1"e	6'1"e	5'0"e	6'10"a	6'10"a	5'7"e	4'1"a
600S137-43	33	8'6"e	7'4"e	6'0"e	8'6"a	8'6"a	6'0"a	8'6"e	7'4"e	6'0"e	8'6"a	8'6"a	7'4"e	6'0"a
600S137-54	50	10'4"	9'5"	8'0"	11'4"i	9'5"	8'0"i	9'5"	8'6"	7'5"	10'6"i	9'7"i	8'0"i	8'0"i
600S137-68	50	11'1"	10'1"	8'9"	12'5"i	11'3"i	9'4"i	10'1"	9'2"	8'0"	11'3"i	10'3"i	8'11"i	8'11"i
600S137-97	50	12'3"	11'1"	9'9"	13'9"i	12'6"i	10'11"i	11'1"	10'1"	8'10"	12'6"i	11'4"i	9'11"i	9'11"i
600S162-33	33	7'7"e	6'7"e	5'4"e	7'1"a	5'9"a	4'3"a	7'7"e	6'7"e	5'4"e	7'1"a	5'9"a	4'3"a	4'3"a
600S162-43	33	9'4"e	8'1"e	6'7"e	9'4"a	8'1"a	6'7"a	9'1"e	8'1"e	6'7"e	9'4"a	8'1"a	6'7"a	6'7"a
600S162-54	50	10'9"	9'9"	8'7"e	12'1"i	10'10"i	8'10"i	9'9"	8'11"	7'9"	11'0"i	10'0"i	8'9"i	8'9"i
600S162-68	50	11'7"	10'6"	9'2"	13'0"i	11'9"i	10'4"i	10'6"	9'6"	8'4"	11'9"	10'8"i	9'4"i	9'4"i
600S162-97	50	12'10"	11'8"	10'2"	14'4"i	11'5"i	11'5"i	11'8"	10'7"	9'3"	13'1"i	11'10"	10'4"i	10'4"i
600S200-33	33	8'1"e	7'0"e	5'9"e	7'4"a	6'0"a	4'4"a	8'1"e	7'0"e	5'9"e	7'4"a	6'0"a	4'4"a	4'4"a
600S200-43	33	9'8"e	8'4"e	6'10"e	9'8"a	8'4"a	6'10"a	9'7"e	8'4"e	6'10"e	9'8"a	8'4"a	6'10"a	6'10"a
600S200-54	50	11'4"	10'3"	9'0"e	12'9"i	11'2"i	9'1"i	10'3"	9'4"	8'2"	11'7"i	10'6"i	9'1"i	9'1"i
600S200-68	50	12'2"	11'0"	9'8"	13'8"i	12'5"i	10'10"i	11'0"	10'0"	8'9"	12'5"i	11'3"i	9'10"i	9'10"i
600S200-97	50	13'6"	12'3"	10'8"	15'2"i	13'9"i	12'0"i	12'3"	11'2"	9'9"	13'9"i	12'6"i	10'11"i	10'11"i
600S250-43	33	9'11"e	8'7"e	7'0"e	9'11"a	8'7"a	7'0"a	9'11"e	8'7"e	7'0"e	9'11"a	8'7"a	7'0"a	7'0"a
600S250-54	50	11'10"	10'9"	9'4"e	13'2"i	11'5"i	9'4"i	10'9"	9'9"	8'6"e	12'1"i	10'11"i	9'4"i	9'4"i
600S250-68	50	12'9"	11'7"	10'1"	14'4"i	13'0"i	10'11"i	11'7"	10'6"	9'2"	13'0"i	11'10"i	10'4"i	10'4"i
600S250-97	50	14'2"	12'10"	11'3"	15'11"i	14'5"i	12'7"i	12'10"	11'8"	10'3"	14'5"i	13'1"i	11'6"	11'6"
600S300-54	50	12'1"	10'11"	9'6"e	13'5"i	11'7"i	9'6"i	10'11"	9'11"	8'8"e	12'4"i	11'2"i	9'6"i	9'6"i
600S300-68	50	13'2"	12'0"	10'5"	14'9"i	13'5"i	11'1"i	12'0"	10'10"	9'6"	13'5"i	12'2"i	10'8"i	10'8"i
600S300-97	50	14'9"	13'4"	11'8"	16'6"i	15'0"i	13'1"i	13'4"	12'2"	10'7"	15'0"i	13'8"i	11'11"i	11'11"i
800S137-33	33	8'1"a	6'6"a	4'4"a	6'4"a	5'1"a	3'5"a	8'1"a	6'6"a	4'4"a	6'4"a	5'1"a	3'5"a	3'5"a
800S137-43	33	9'9"e	8'6"e	6'11"e	9'9"a	8'3"a	6'2"a	9'9"e	8'6"e	6'11"e	9'9"a	8'3"a	6'2"a	6'2"a
800S137-54	50	12'11"	11'5"	9'3"e	13'2"i	11'5"i	9'3"i	11'9"	10'8"	9'3"e	13'2"i	11'5"i	9'3"i	9'3"i
800S137-68	50	14'0"	12'9"	10'11"	15'6"i	13'5"i	10'11"i	12'9"	11'7"	10'1"	14'3"i	13'0"i	10'11"i	10'11"i
800S137-97	50	15'7"	14'2"	12'4"	17'5"i	15'10"i	13'10"i	14'2"	12'10"	11'3"	15'10"i	14'5"i	12'7"i	12'7"i
800S162-33	33	8'7"a	6'6"a	4'4"a	6'7"a	5'2"a	3'5"a	8'7"a	6'6"a	4'4"a	6'7"a	5'2"a	3'5"a	3'5"a
800S162-43	33	10'7"e	9'2"e	7'5"e	10'7"a	8'8"a	6'7"a	10'7"e	9'2"e	7'5"e	10'7"a	8'8"a	6'5"a	6'5"a
800S162-54	50	13'6"	12'3"e	10'0"e	14'1"i	12'3"i	10'0"i	12'3"	11'1"	9'9"e	13'9"i	12'3"i	10'0"i	10'0"i
800S162-68	50	14'7"	13'3"	11'7"	16'4"i	14'4"i	11'8"i	13'3"	12'0"	10'6"	14'10"i	13'6"i	11'8"i	11'8"i
800S162-97	50	16'2"	14'9"	12'10"	18'2"i	16'6"i	14'5"i	14'9"	13'4"	11'8"	16'6"i	15'0"i	13'1"i	13'1"i

Notes:

- 1 Web punchouts are not considered for shear and web crippling.
- 2 Deflection checks are computed using unbalanced loads for the two equal span conditions.

- 3 "e" indicates that the web stiffeners are required at the end support only.
- 4 "i" indicates that the web stiffeners are required at the interior support only.
- 5 "a" indicates that the web stiffeners are required at all supports.

6 Long spans utilizing shallow depth members may result in serviceability (annoying bounce) issues.

7 See additional floor joint notes on page 67.

# FLOOR JOIST SPAN LIMITATIONS

## 10psf Dead Load and 100psf Live Load (TL Deflection=L/240)

Member	Yield strength F <sub>y</sub> (ksi)	Live Load Deflection L/360						Live Load Deflection L/480					
		Single span spacing (in) o.c.			Two equal span spacing (in) o.c.			Single span spacing (in) o.c.			Two equal span spacing (in) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
800S200-33	33	8'7" a	6'6" a	4'4" a	6'9" a	5'2" a	3'5" a	8'7" a	6'6" a	4'4" a	6'9" a	5'2" a	3'5" a
800S200-43	33	11'3" e	9'9" e	8'0" e	11'0" a	9'0" a	6'8" a	11'3" e	9'9" e	8'0" e	11'0" a	9'0" a	6'8" a
800S200-54	50	14'3" e	12'11" e	10'8" e	15'1" i	13'0" i	10'8" a	12'11" e	10'8" a	10'3" e	14'6" i	13'0" i	10'8" a
800S200-68	50	15'3" e	13'10" i	12'1" e	17'2" i	15'7" i	12'11" i	13'10" i	12'7" i	11'0" i	15'7" i	14'2" i	12'4" i
800S200-97	50	17'0" e	15'5" i	13'6" i	19'1" i	17'4" i	15'2" i	15'5" i	14'0" i	12'3" i	17'4" i	15'9" i	13'9" i
800S250-43	33	11'7" e	10'0" e	8'2" e	11'2" a	9'2" a	6'9" a	11'7" e	10'0" e	8'2" e	11'2" a	9'2" a	6'9" a
800S250-54	50	14'9" e	13'4" e	10'11" e	15'5" i	13'4" i	10'9" a	13'5" i	12'2" e	10'8" e	15'1" i	13'4" i	10'9" a
800S250-68	50	15'11" e	14'6" i	12'8" e	17'11" i	15'8" i	12'9" i	14'6" i	13'2" i	11'6" i	16'3" i	14'9" i	12'9" i
800S250-97	50	17'9" e	16'1" i	14'1" i	19'11" i	18'1" i	15'10" i	16'1" i	14'8" i	12'10" i	18'1" i	16'5" i	14'4" i
800S300-54	50	15'1" e	13'6" e	11'1" e	15'7" i	13'6" i	10'11" a	13'9" i	12'5" e	10'11" e	15'5" i	13'6" i	10'11" a
800S300-68	50	16'5" e	14'11" i	13'0" e	18'4" i	15'11" i	13'0" i	14'11" i	13'6" i	11'10" i	16'9" i	15'2" i	13'0" i
800S300-97	50	18'4" e	16'8" i	14'7" i	20'7" i	18'9" i	16'4" i	16'8" i	15'2" i	13'3" i	18'9" i	17'0" i	14'10" i
1000S162-43	33	11'8" a	10'1" a	7'7" a	10'2" a	8'2" a	5'11" a	11'8" a	10'1" a	7'7" a	10'2" a	8'2" a	5'11" a
1000S162-54	50	15'8" e	13'7" e	11'1" e	15'8" i	13'2" i	9'11" a	14'7" i	13'3" e	11'1" e	15'8" i	13'2" i	9'11" a
1000S162-68	50	17'4" e	15'9" i	13'1" e	18'6" i	16'0" i	13'1" i	15'9" i	14'4" i	12'6" e	17'9" i	16'0" i	13'1" i
1000S162-97	50	19'6" e	17'9" i	15'6" i	21'11" i	19'11" i	16'9" i	17'9" i	16'1" i	14'1" i	19'11" i	18'1" i	15'9" i
1000S200-43	33	12'7" a	10'11" a	7'7" a	10'7" a	8'6" a	6'1" a	12'7" a	10'11" a	7'7" a	10'7" a	8'6" a	6'1" a
1000S200-54	50	16'9" e	14'7" e	11'11" e	16'10" i	13'9" a	10'3" a	15'3" i	13'10" e	11'11" e	16'10" i	13'9" a	10'3" a
1000S200-68	50	18'2" e	16'6" i	14'0" e	19'9" i	17'2" i	14'0" a	16'6" i	15'0" i	13'1" e	18'6" i	16'10" i	14'0" a
1000S200-97	50	20'4" e	18'6" i	16'2" i	22'10" i	20'9" i	17'10" i	18'6" i	16'10" i	14'8" i	20'9" i	18'11" i	16'6" i
1000S250-54	50	17'3" e	14'11" e	12'3" e	17'1" i	14'0" a	10'5" a	16'1" e	14'7" e	12'3" e	17'1" i	14'0" a	10'5" a
1000S250-68	50	19'0" e	17'3" i	14'4" e	20'4" i	17'7" i	14'4" a	17'3" i	15'8" i	13'9" e	19'5" i	17'7" i	14'4" a
1000S250-97	50	21'3" e	19'3" i	16'10" i	23'10" i	21'8" i	18'11" i	19'3" i	17'6" i	15'4" i	21'8" i	19'8" i	17'2" i
1000S300-54	50	17'6" e	15'2" e	12'5" e	17'3" i	14'1" a	10'6" a	16'5" e	14'1" e	12'5" e	17'3" i	14'1" a	10'6" a
1000S300-68	50	19'7" e	17'9" e	14'7" e	20'8" i	17'11" i	14'7" a	17'9" i	16'2" i	14'1" e	19'11" i	17'11" i	14'7" a
1000S300-97	50	21'11" e	19'11" i	17'11" i	24'7" i	22'4" i	18'9" i	19'11" i	18'1" i	15'9" i	22'4" i	20'3" i	17'9" i
1200S162-54	50	16'10" a	14'7" a	11'11" a	15'8" a	12'8" a	9'4" a	16'9" a	14'7" a	11'11" a	15'8" a	12'8" a	9'4" a
1200S162-68	50	20'0" e	17'4" e	14'2" e	20'0" i	17'4" i	14'1" a	18'2" i	16'6" i	14'2" e	20'0" i	17'4" i	14'1" a
1200S162-97	50	22'8" e	20'7" i	18'0" i	25'6" i	22'6" i	18'4" i	20'7" i	18'9" i	16'4" i	23'2" i	21'0" i	18'4" i
1200S200-54	50	18'3" a	15'9" a	12'6" a	16'4" a	13'2" a	9'8" a	17'6" a	15'9" a	12'6" a	16'4" a	13'2" a	9'8" a
1200S200-68	50	20'11" e	18'8" e	15'3" e	21'7" i	18'8" i	14'9" a	19'0" i	17'3" e	15'1" e	21'4" i	18'8" i	14'9" a
1200S200-97	50	23'8" e	21'6" i	18'9" i	26'6" i	24'0" i	19'7" i	21'6" i	19'6" i	17'0" i	24'1" i	21'11" i	19'2" i

### Notes:

- 1 Web punchouts are not considered for shear and web crippling.
- 2 Deflection checks are computed using unbalanced loads for the two equal span conditions.

- 3 "e" indicates that the web stiffeners are required at the end support only.
- 4 "i" indicates that the web stiffeners are required at the interior support only.
- 5 "a" indicates that the web stiffeners are required at all supports.

6 Long spans utilizing shallow depth members may result in serviceability (annoying bounce) issues.

7 See additional floor/joint notes on page 67.

FLOOR JOIST SPAN LIMITATIONS 10psf Dead Load and 100psf Live Load (TL Deflection=L/240)

Member	Yield strength F <sub>y</sub> (ksi)	Live Load Deflection L/360						Live Load Deflection L/480					
		Single span spacing (in) o.c.			Two equal span spacing (in) o.c.			Single span spacing (in) o.c.			Two equal span spacing (in) o.c.		
		12	16	24	12	16	24	12	16	24	12	16	24
1200S250-54	50	18'10" a	16'4" a	12'6" a	16'7" a	13'5" a	9'9" a	18'3" a	16'4" a	12'6" a	16'7" a	13'5" a	9'9" a
1200S250-68	50	21'9"	19'3" e	15'9" e	22'3" i	19'3" i	15'1" a	19'9"	18'0" e	15'8" e	22'2" i	19'3" i	15'1" a
1200S250-97	50	24'7"	22'4"	19'6"	27'7" i	24'10" i	20'3" i	22'4"	20'3" i	17'8"	25'0" i	22'9" i	19'10" i
1200S300-54	50	19'2" a	16'7" a	12'6" a	16'10" a	13'6" a	9'10" a	19'0" a	16'7" a	12'6" a	16'10" a	13'6" a	9'10" a
1200S300-68	50	22'8" e	19'8" e	16'0" e	22'8" i	19'8" a	15'3" a	20'7"	18'8" e	16'0" e	22'8" i	19'8" a	15'3" a
1200S300-97	50	25'4"	23'0"	20'1"	28'5" i	25'4" i	20'8" i	23'0"	20'11" a	18'3"	25'10" i	23'5" i	20'6" i
1400S162-54	50	17'9" a	15'5" a	10'8" a	14'11" a	12'0" a	8'7" a	17'9" a	15'5" a	10'8" a	14'11" a	12'0" a	8'7" a
1400S162-68	50	21'3"	18'5" e	15'0" e	21'3" i	18'3" i	13'8" a	20'6"	18'5" e	15'0" e	21'3" i	18'3" i	13'8" a
1400S162-97	50	25'9"	23'4"	19'8"	27'10" i	24'2" i	19'8" i	23'4"	21'3" i	18'7"	26'3" i	23'10" i	19'8" i
1400S200-54	50	19'4" a	16'0" a	10'8" a	15'7" a	12'5" a	8'7" a	19'4" a	16'0" a	10'8" a	15'7" a	12'5" a	8'7" a
1400S200-68	50	23'0" e	19'11" e	16'3" e	23'0" i	19'2" a	14'4" a	21'5"	19'5" e	16'3" e	23'0" i	19'2" a	14'4" a
1400S200-97	50	26'9"	24'3"	21'1" e	29'10" i	25'10" i	21'1" i	24'3"	22'1" i	19'3"	27'3" i	24'9" i	21'1" i
1400S250-54	50	20'1" a	16'0" a	10'8" a	15'10" a	12'7" a	8'7" a	20'1" a	16'0" a	10'8" a	15'10" a	12'7" a	8'7" a
1400S250-68	50	23'10" e	20'8" e	16'10" e	23'10" i	19'7" a	14'7" a	22'3" e	20'2" e	16'10" e	23'10" i	19'7" a	14'7" a
1400S250-97	50	27'8"	25'2"	21'11" e	30'11" i	26'10" i	21'11" i	25'2"	22'10" a	20'0"	28'3" i	25'8" i	21'11" i
1400S300-54	50	20'7" a	16'0" a	10'8" a	16'0" a	12'8" a	8'7" a	20'7" a	16'0" a	10'8" a	16'0" a	12'8" a	8'7" a
1400S300-68	50	24'5" e	21'2" e	17'3" e	24'3" i	19'10" a	14'9" a	22'10" e	20'9" e	17'3" e	24'3" i	19'10" a	14'9" a
1400S300-97	50	28'7"	25'11" a	22'5" e	31'8" i	27'5" i	22'5" i	25'11" a	23'7" i	20'7" i	29'1" i	26'5" i	22'5" i

Notes:

- 1 Web punchouts are not considered for shear and web crippling.
- 2 Deflection checks are computed using unbalanced loads for the two equal span conditions.

- 3 "e" indicates that the web stiffeners are required at the end support only.
- 4 "i" indicates that the web stiffeners are required at the interior support only.
- 5 "a" indicates that the web stiffeners are required at all supports.

6 Long spans utilizing shallow depth members may result in serviceability (annoying bounce) issues.

7 See additional floor joist notes on page 67.